

## Installation guide



- For indoor use only.
- Product installation must be carried out by a qualified professional.
- Before installing make sure, that electrical power is turned **OFF**.
- Before installing make sure, that the fixing area can bear the total weight of the luminaire.
- Pay attention to polarity when connecting (installing) the product.
- Do not operate if the luminaire has been damaged.
- To protect the surface from dirt and fingerprints, we recommend the use of protective gloves during installation.
- Product warranty does not cover any damage caused by faulty installation and/or misuse.
- For further information, please contact the manufacturer.

Luminaire	Cutting hole size, mm (ft)	Luminaire	Cutting hole size, mm (ft)
L-560	562 x 52 mm (1.84' x 2.05')	L-1960	1962 x 52 mm (6.44' x 2.05')
L-840	842 x 52 mm (2.76' x 2.05')	L-2240	2242 x 52 mm (7.36' x 2.05')
L-1120	1122 x 52 mm (3.68' x 2.05')	L-2520	2522 x 52 mm (8.27' x 2.05')
L-1400	1402 x 52 mm (4.6' x 2.05')	L-2800	2802 x 52 mm (9.19' x 2.05')
L-1680	1682 x 52 mm (5.52' x 2.05')	L-3080	3082 x 52 mm (10.11' x 2.05')

Min ceiling thickness 10 mm (0.39 in)    Max ceiling thickness 16 mm (0.63 in)

**1**

REMOVE INSERT EXTRUSION

REMOVE COVER

*For insert extrusion unlock and removal see pic. No. 14*

**2**

**3**

**4**

VIEW ABOVE THE CEILING

**5**

MEASURE DISTANCES

**6**

**7**

REMOVE DUMMY

**8**

