

## Installation guide



- For indoor use only.
- Product installation must be carried out by a qualified professional.
- Before installing make sure, that electrical power is turned **OFF**.
- Before installing make sure, that the fixing area can bear the total weight of the luminaire.
- Pay attention to polarity when connecting (installing) the product.
- Do not operate if the luminaire has been damaged.
- To protect the surface from dirt and fingerprints, we recommend the use of protective gloves during installation.
- Product warranty does not cover any damage caused by faulty installation and/or misuse.
- For further information, please contact the manufacturer.

Luminaire	Cutting hole size by Segment type, mm (ft)				Width	Luminaire	Cutting hole size by Segment type, mm (ft)				Width
	Start	Middle	End	End			Start	Middle	End	End	
L-560	561 (1.84')	560 (1.84')	561 (1.84')		52 mm (2.05")	L-1960	1961 (6.43')	1960 (6.43')	1961 (6.43')		52 mm (2.05")
L-840	841 (2.76')	840 (2.76')	841 (2.76')			L-2240	2241 (7.35')	2240 (7.35')	2241 (7.35')		
L-1120	1121 (3.68')	1120 (3.67')	1121 (3.68')			L-2520	2521 (8.27')	2520 (8.27')	2521 (8.27')		
L-1400	1401 (4.6')	1400 (4.59')	1401 (4.6')			L-2800	2801 (9.19')	2800 (9.19')	2801 (9.19')		
L-1680	1681 (5.52')	1680 (5.51')	1681 (5.52')			L-3080	3081 (10.11')	3080 (10.1)	3081 (10.11')		
<b>Example:</b> 561+560+561=1688 mm				<b>Cutting hole size:</b> 1682 mm x 52 mm (5.52' x 2.05')							

Min ceiling thickness 10 mm (0.39 in)    Max ceiling thickness 16 mm (0.63 in)

1

REMOVE INSERT EXTRUSION

REMOVE COVER

*For insert extrusion unlock and removal see pic. No. 19*

2

3

4

MEASURE DISTANCES

5

VIEW ABOVE THE CEILING

6

7



